

Arming the System

** (Your system must have a green ready light to arm, this means all doors and windows are closed) **

- When leaving an empty house Press and hold AWAY button for 3 seconds
- When persons or pets are inside Press and hold STAY button for 3 seconds
- When going to sleep (no one exiting/entering home) Press *9 and your 4 Digit Code

Disarming the System

- To turn off the system at any time Enter Your 4 Digit Code

Adding or changing a User Code (Up to 32 Users)

- To change your code:

Press *5 Your 4 Digit Master Code then
01 and a new 4 digit code
to end

- To add codes for guests, workers, etc.:

Press *5 Your 4 Digit Master Code then
02 and a new 4 digit code
to end

If you need to add more codes repeat above changing location 02 as in above to 03, 04, 05 ... Upto 32

Setting Time & Date

** (Time HH/MM must be set using a 24 hr. Military format.
Date must be set as MM/DD/YY format) **

Example: 3:09 pm March 21, 2011 = (15:09) (03/21/11)

- Press *6 your 4 digit Master Code, then 1
Enter time HH/MM, enter date MM/DD/YY and end with ##

Zone Bypass

- Press *1, then the 2 digit zone to be bypassed, and end with ##
Wait ten seconds, if green ready light is on, arm system as usual

Smoke Detectors

If smoke detector has set off the siren and there is no fire:

- To turn off loud alarm enter your 4 Digit Code
- Fan smoke detectors until air is clear, and then reset alarm
- To reset alarm press & hold RESET button for 3 seconds
- If your system does not have a RESET button enter *72

Door Chime

- To activate door chimes press and hold the CHIME button until it beeps or for 3 seconds
- To deactivate door chimes press and hold the CHIME button until it beeps or for 3 seconds
- If your system does not have a CHIME button enter *4 at the keypad

Testing your system

** (Testing should be done regularly to make sure system is in good working order) **

- Call the Central Monitoring Station at 416-913-0419 and let them know you are going to test your alarm system
- Give them your 8 digit Passcode
- Arm you system wait 60 seconds to activate the alarm, trip all of your alarm sensors, wait 30 seconds and then disarm your system using your 4 digit code
- Call Central Monitoring Station back to verify they received your signals